

3 2RXpGy2Vc

(SPEECH)

[00:00:00.00] [MUSIC PLAYING]

(DESCRIPTION)

[00:00:00.00] Logo, Bissell.

(SPEECH)

[00:00:01.95] Now that you are finished cleaning, follow our helpful tips to ensure your machine is properly stored to be ready for the next time you clean.

[00:00:08.07] First, check if there is a solution remaining in the tank bladder. If there is, please empty and then fill the tank with warm tap water.

[00:00:15.84] Next, replace the tank on your machine. Turn the power on and recline the handle while pressing the spray trigger. Make a few forward and backward passes for about 15 seconds.

[00:00:25.56] Release the trigger to suction up the water and then repeat for another 15 seconds. Continue over the area until no more water is being suctioned.

[00:00:34.05] Now that your machine has been flushed and is ready to be stored.

(DESCRIPTION)

[00:00:37.65] Bissell. Text, Home to a deeper clean. Bissell dot com. Ask us! Facebook and Twitter logos.