

M-j6ctriNIU

(SPEECH)

[00:00:00.00] [MUSIC PLAYING]

(DESCRIPTION)

[00:00:00.00] Bissell CrossWave Pet Pro, Cleaning Machine After Use, two bottles sit next to the machine

(SPEECH)

[00:00:05.13] The Easy Clean Storage Tray helps you both clean and store your CrossWave Pet Pro. To clean your machine, place it onto the storage tray. Pour water into the rinse funnel, filling up to the max line. Turn on your machine by pressing the hard floor button. Recline your machine backwards while in the storage tray.

(DESCRIPTION)

[00:00:23.43] Machine runs

(SPEECH)

[00:00:24.09] Let the machine run for 10 to 15 seconds until all the water is picked up, then unplug the cord from the outlet. If any moisture is left over in the tray from cleaning, wipe it dry with a paper towel or cloth.

(DESCRIPTION)

[00:00:37.56] A woman wipes the tray dry

(SPEECH)

[00:00:39.87] Remove the brush roll window by grabbing the front and pulling up. Pull out the brush roll by grabbing the tab and pulling up. Put the brush roll upright onto the brush roll drying tray to let it dry. Reinsert the brush roll, then lock the pole tab into place by pressing downward. Reinsert the brush roll window by lining up the tabs with the edges of the foot. Push the brush roll window back into place until you hear a click.

[00:01:05.40] Now to empty and clean the dirty water tank. To remove, grab the handle in front of the dirty water tank and press down on the release button.

(DESCRIPTION)

[00:01:13.01] Above handle

(SPEECH)

[00:01:14.07] Grasp the top of the tank and pull up to remove it. Now pull out the strainer, place the debris in a wastebasket, and rinse under running water. Empty the dirty water into a sink, then rinse your tank.

(DESCRIPTION)

[00:01:26.85] The woman swirls water around the tank to clean it and dumps it down the drain.

(SPEECH)

[00:01:32.49] Remove the filter from the top of the tank by pulling up. Hand wash the filter and screen using warm water, then rinse the float, located on the bottom of the dirty water bin's top. If the inside area where the dirty water tank sits is dirty, wipe it clean with a rag or towel. Leave the parts out to dry before reassembling.

[00:01:52.20] Once dry, place the vacuum filter back into the dirty water tank top, then place the strainer in the dirty water tank. Now replace the top of the dirty water tank. To place the tank back on the machine, insert the bottom first at an angle and push it into place until you hear a click.

(DESCRIPTION)

[00:02:09.66] The machine is assembled. Bissell, home to a deeper clean.